
The maximum bytes in a TCP header can be 60 bytes..in the chosen packet 7415 frame..there are 56 bytes.



The different fields in TCP headers are:

- **Source port**: this is a 16 bit field that specifies the port number of the sender.
- **Destination port**: this is a 16 bit field that specifies the port number of the receiver.
- **Sequence number**: the sequence number is a 32 bit field that indicates how much data is sent during the TCP session.
- **Acknowledgment number**: this 32 bit field is used by the receiver to request the next TCP segment. This value will be the sequence number incremented by 1.
- **Data Offset**: this is the 4 bit data offset field, also known as the header length. It indicates the length of the TCP header so that we know where the actual data begins.
- **Reserved**: these are 3 bits for the reserved field. They are unused and are always set to 0.
- **Flags**: there are 9 bits for flags, we also call them control bits. We use them to establish connections, send data and terminate connections:
  - **URG**: urgent pointer. When this bit is set, the data should be treated as priority over other data.
  - o **ACK**: used for the acknowledgment.
  - PSH: this is the push function. This tells an application that the data should be transmitted immediately and that we don't want to wait to fill the entire TCP segment.
  - o **RST**: this resets the connection, when you receive this you have to terminate the connection right away. This is only used when there are unrecoverable errors and it's not a normal way to finish the TCP connection.
  - **SYN**: we use this for the initial three way handshake and it's used to set the initial sequence number.

- o **FIN**: this finish bit is used to end the TCP connection. TCP is full duplex so both parties will have to use the FIN bit to end the connection. This is the normal method how we end a connection.
- **Window**: the 16 bit window field specifies how many bytes the receiver is willing to receive. It is used so the receiver can tell the sender that it would like to receive more data than what it is currently receiving. It does so by specifying the number of bytes beyond the sequence number in the acknowledgment field.
- Checksum: 16 bits are used for a checksum to check if the TCP header is OK or not.
- **Urgent pointer**: these 16 bits are used when the URG bit has been set, the urgent pointer is used to indicate where the urgent data ends.

In the above packet following are the respective values of TCP headers:

**Source Port**: 6666 **Destination Port**: 55738 **Sequence Number:** 1789

**Acknowledgment Number: 4222** 

**Data offset: 5** (header length is 20 bytes)

Reserved: 0

Flags: 0x010 (ACK) (this means only ACK flag is set)

Window Size: 83

**Checksum:** 0xab19 **status:** unverified (this means checksum validation has not been

performed)

**Urgent Pointer**: 0